PYLE

PyleUSA.com

USER MANUAL

PLDVRWF165

PYLE

www.pyleusa.com/contactus

CONTENTS

Front Panel 1
Packing Content 1
Features 2
Warnings 2
IOS System Installation Guide 2
Connection on IOS System 3
Android System Installation Guide 3
Connection on Android System 3
Install Car DVR APP 4
Camera List 4
APP Main Interface 5
Resolution Settings 6
Trouble shooting 8
Installation 9

Front Panel

Packing Content

* 1 x DVR unit
* 1 x Power cord
* 1 x User manual
* 1 x Warranty card

Features

- Supports full HD 1080P video recording (30fps)
- Lens angle: 170°
- With high speed SD card (optional)
- Supports Wi-Fi, operation can be done through mobile devices after Wi-Fi connected.

Warnings

To ensure your personal safety and to avoid the damage of products, please observe the following instructions and safety rules.

- This unit is for car use only.
- DO NOT operate the unit or use the DVR APP while driving.
- DO NOT use this unit at abnormal temperature.
- DO NOT use the unit in strong magnetic or violent vibration field.
- ONLY use the power cord provided with the unit. Use of non-standard power cord may cause problems.

IOS System Installation Guide

Open 'APP STORE', enter 'RORO CAM' in the search bar, click 'download' and install the APP or scan the QR code below:

RORO-IOS

Connection on IOS System

1.Click 'Setting' ---> 'Wi-Fi'.
2.Choose 'PLDVRWFI65'.
3.Enter Wi-Fi security password '12345678' and connect.
4.Once the connection is successful, open APP, 'Wi-Fi connection successful' will be shown on screen and it will start recording.

Android System Installation Guide

Open 'GOOGLE PLAY' or other application platform, enter 'RORO CAM' in the search bar, click 'download' and install the APP or scan the QR code below:

RORO-Android

Connection on Android System

1. Click 'Setting' ---> 'Wi-Fi'.
2. Choose ‘PLDVRWFI65'.
3. Enter Wi-Fi security password '12345678' and connect.
4. Once the connection is successful, open APP, 'Wi-Fi connection successful' will be shown on screen and it will start recording.

Install Car DVR APP



Camera List

APP Main Interface

1. Start/ Stop recording. is video preview and means DVR is recording.
2. Photograph. means it is taking photographs. This function is unavailable when recording.
3. Video watermark
4. Sound recording. is sound recording off, is sound recording on.
5. Click to enter setting menu.
6. Click to set recording resolution: 1080P(1920X1080), 720P(1080X720), WVGA (848X480), VGA (640X480).
7. Click to enter DVR SD card file list.
8. Click to return to main menu.
9. Recording icon and time. When recording off, it shows as and time is '0'; when recording on, it is red color as and shows video recording time.
10. power indicator
11. 17:13 phone clock.
12. In the preview screen, slide up to enhance mobile phone backlight and slide down to reduce backlight.

Resolution Settings

Setting



Setting



Advanced Setting



File Directory

Picture Directory

Preview Directory



Preview

File Download

Trouble Shooting

Problems	Solutions
APP cannot add camera	1. Uninstall the APP and install again. 2. Disconnect Wi-Fi on mobile phone and search again. 3. Reconnect Wi-Fi. 4. Re-install APP and add camera again.
Cannot record video and sound normally.	1. Change to high speed TF card or format the TF card. 2. Change video resolution. 3. Check and make sure the TF card is installed properly. 4. Delete some unnecessary file from TF card to release space.
Video is not sharp	1. Change video resolution. 2. Check the camera lens. Wipe the dust and dirt off the lens before recording.
DVR can work but buttons no function DVR crashed	Press the RESET button with a pin and restart the system.
Video lag or noise when using computer playback.	Try to play it with other media player. Noise may be caused by speaker. Check if speaker is working properly. It is suggested to play it on a laptop.
Video mosaic or lag when using mobile phone playback.	1. Put your mobile close to the DVR to enhance Wi-Fi signal. 2. Decrease video resolution. 3. Change to a mobile with higher configuration.

Installation